


# 寸法表

## コンドルファ始動器

形式	電圧	容量	外形図	W	D	H	質量 (kg)
KS	200/220V	15	A	300	190	250	32
		22	B	350	190	275	37
		37		390	200	310	51
		55		430	210	345	68
		75		430	230	355	84
		110		430	240	460	100
		150		490	260	495	134
		220		520	260	565	185
	400/440V	15	A	300	190	250	32
		22	B	350	200	295	40
		37		380	190	345	55
		55		390	220	345	68
		75		420	220	375	85
		110		420	240	385	97
		150		460	240	430	125
		220		490	270	515	151
		300		540	295	575	209
		400		540	310	605	247
		500		570	310	625	277
	3000/3300V	55	B	620	305	520	110
		75		620	280	550	113
		110		620	295	550	120
		150		620	320	570	150
		220		620	345	595	173
		250		670	355	625	215
		300		670	350	645	239
		400		670	385	700	283
		500		690	405	710	325
		600		690	405	730	363
		710		720	425	750	407
		800		720	425	760	447
		900		750	425	760	479
		1000		780	455	835	529
		1250		820	465	855	601
	6000/6600V	75	B	620	315	610	143
		110		620	325	610	149
		150		620	330	615	178
		220		620	345	615	200
		300		670	355	650	256
		400		670	365	695	297
		500		670	385	695	328
		600		670	405	705	373
		710		700	405	760	417
		800		700	425	760	439
		900		720	415	795	496
		1000		720	430	805	548
		1250		750	430	860	637
		1600		750	455	870	717

形式	電圧	容量	外形図	W	D	H	質量 (kg)
KC	200/220V	3.7	A	150	145	210	12
		7.5		200	185	210	20
		15		300	190	250	35
		22	B	350	230	275	50
		37		400	240	325	85
		55		455	270	355	100
		75		540	280	390	130
		110		515	280	470	170
		150		515	300	505	190
	400/440V	7.5	A	200	180	210	18
		15	B	300	190	250	35
		22		350	230	275	50
		37		400	240	320	80
		55		400	260	345	100
		75		455	270	390	130
		110		470	290	435	175
		150		540	300	435	200
		220		540	380	490	255
		300		600	380	520	400
	3000/3300V	45	B	550	300	390	165
		75		550	330	445	210
		110		600	330	500	260
		150		650	370	525	340
		220		700	420	540	480
		250		720	420	575	510
		300		720	450	575	575
		370		750	470	575	630
	6000/6600V	110	B	630	380	505	290
		150		690	390	525	355
		220		780	430	540	465
		300		840	480	575	595
		375		840	520	575	680

[A]



[B]

